

# WIRING DIAGRAM

## 1980-1981 MODELS

NOTE: THERMOSTAT MUST BE GROUNDED BEFORE POWER IS APPLIED. OTHERWISE, MODULE WILL BE DAMAGED.

